


MOTIONGREY

Assembly Instruction -


Ergo2 Series Standing Desk S

(43" X 24")




SCREW ACCESSORIES

S1



6mm Allen Key **x1**

S2




3mm Allen Key **x1**

S3



Bracket Screw (M8) **x13**

S4




Metal Rod Connector Screw (M5) **x2**

S5



Frame Screw (M4) **x2**

S6




Foot Base & Motor Screw (M8) **x8**

S7




Wire Clip **x3**

S8



Footer **x4**


S9



Wood Screw (M4) **x28**


PARTS ACCESSORIES

A



Frame **x2**

B




Central Bracket **x2**

C



Metal Frame Connector **x2**

D




Motor **x1**

E



Metal Rod #1 **x1**

F




Metal Rod Connector **x1**

G




Metal Rod #2 **x1**

H



Foot Base **x2**

I



Side Bracket **x2**

J




Table Top **x1**

K




Cable Clip **x1**

L



Headphone Hook **x1**


M




Cup Holder **x1**

STEP 1

A*2



B




S3




x6

S1




x1




STEP 2

B



C*2



S3




x2

S1



x1




STEP 3


E




D



F



S3




x1


S1




x1




STEP 4




STEP 5




STEP 6



STEP 7



STEP 8



STEP 9

